

## AD20/AD35 Food Mix Exploded diagram Parts List

No.	name	No.	name
1	nut	56	head worm bar
2	spring washer	57	stator
3	Skeleton oil seal	58	worm shaft 15 teeth
4	axis with snap spring	59	worm gear 23 teeth
5	bearing	60	guide shaft
6	Bearing on the next set of	62	shifting fork spring
7	clutch gear up	63	shifting fork small shaft
8	output shaft gear sets	64	shifting fork
9	flat key	65	Eccentric Shaft
10	output shaft	66	screw
11	flat key	67	variable-speed shaft
12	flat key	68	gear handle
13	output shaft clutch	69	locating spring
14	clutch gear up	70	ring seal
15	Ratchet plate(up)	71	gear shifting seat
16	Outer Ring	72	indicator
17	Roller Spring	73	button head screw
18	Roller	74	planet gear 20 teeth
19	Inside the star wheels	75	ball bearing
20	Ratchet plate(under)	76	ball bearing
21	bearing	77	oil seal
22	flat pad	78	flat key
23	spring washer	79	taper bolt
24	nut	80	agitating shaft
25	nut	81	centrifugal starter
26	spring washer	82	button head screw
27	Plain washer	83	back axle bearing seat
28	bearing	84	fan blade
29	Between the bridge axis	85	back air hood
30	flat key	86	socket head screw
31	Intermediate shaft gear(big)	87	dough mixer
32	Axial length between sets of	88	agitator
33	Intermediate shaft gear(small)	89	egg beater
34	Shaft ring	90	charging basket
35	bearing	91	rack
36	front name plate	92	pressing handle
37	net hood	93	pressing handle inner jacket
38	socket head screw	94	charging basket locating pin
39	internal gear	95	spring washer
40	internal the hexagon screw	96	socket head screw
41	shifting seat	97	pier
42	oil ring	98	hexagon screw
43	case	99	hexagon bolt
44	axle bearing seat cover	100	pressure plate
45	socket head screw	101	foot
46	pressure plate	102	fixed sleeve
47	pressure plate	103	socket head screw
48	socket head screw	104	joystick
49	button head screw	105	lifter screw
50	cap	106	pin bolt
51	rotor	107	cotter pin
52	rotor	108	Lift rod
53	flat key	109	nut
54	bearing	110	Increase the flat pad
55	ring seal	111	Compression spring

# V. Structure and name of the part 20K/30K

